




**SPACE**  
**BETWEEN**

**1**


The propeller only fits in one direction, so try rotating it. It should spin easily.

**2**


Ensure that the hook fits into the detail.

**3**

Turn to the right to secure the detail. Shake the mug to test it. You should be able to hear the propeller.

**4**

Insert the straw. The length can be adjusted by trimming it.

**5**

Thread the straw through and press the lid into place.

**6**


USB type-C

Lighting



The USB-C adapter must support both power and data.






Download SpaceBetween from either the App Store or Google Play. Open the app and log in with your credentials.




## Efter användning

1



Disassemble all parts and remove the check valve. Wash them thoroughly and rinse. Any remaining residue may affect the functionality of the product.

2



Disassemble all parts and remove the check valve. Wash them thoroughly and rinse. Any remaining residue may affect the functionality of the product.

By following these guidelines, you can ensure optimal use and long-term durability of your mug. Remember, we are here for you; don't hesitate to contact us if you have any questions or concerns. We are available to assist and ensure a positive experience with our product. You can find our contact details on our website: [spacebetween.se](https://spacebetween.se).

## **Cleaning:**

- For optimal hygiene, wash, rinse, and dry the mug before its first use. This will ensure that any production residues or dust are removed.
- The product is specifically designed for hand washing and should not be placed in the dishwasher. Dishwashers can damage the mug's surface and structures, potentially affecting its performance and lifespan. Hand washing is the best method to maintain the mug's quality.
- After each use, always empty the mug and clean it with a mild mixture of water and dish soap. This will remove any residue or stains and maintain the mug's freshness and cleanliness. The use of the provided straw brush is recommended to reach hard-to-clean areas.
- To avoid surface scratches, refrain from using abrasive cleaning agents or harsh scrubbing tools. These may damage the mug's surface and diminish its aesthetic quality over time.

## **Important:**

- Sip2play is CE-certified and can be used by children under 3 years old. The mug must always be assembled correctly and in complete condition before being presented to the user. An adult must always supervise during use.
- Before use, carefully inspect the mug for any visible damage, such as scratches, cracks, or deformations. Never use a damaged mug, as this may pose risks to the user and affect the product's functionality.
- To maintain the mug's structure and appearance, avoid exposing it to extreme temperatures, whether hot or cold. Plastic materials can deform or lose their properties at high temperatures.
- Never use boiling liquids in the mug, as this can damage the plastic and create risks for the user. Liquids should be poured into the mug only after they have cooled to a safe temperature.
- To prevent potential bacterial growth, avoid leaving contents in the mug for extended periods. If contents are stored in the mug, ensure they are consumed within a reasonable time and that the mug is thoroughly cleaned between uses.